




Download the
ONECTA app

 **STAND BY ME**
Discover our service offer



Operation manual

Wall Mounted Split Air Conditioner



CTXA15E2V1BW/B/S/G/P/L/C/Y
FTXA20E2V1BW/B/S/G/P/L/C/Y
FTXA25E2V1BW/B/S/G/P/L/C/Y
FTXA35E2V1BW/B/S/G/P/L/C/Y
FTXA42E2V1BW/B/S/G/P/L/C/Y
FTXA50E2V1BW/B/S/G/P/L/C/Y

Operation manual
Wall Mounted Split Air Conditioner

English

Table of Contents

1	About the documentation	2
1.1	Product code	2
1.2	About this document	2
1.2.1	Meaning of warnings and symbols	3
2	User safety instructions	3
2.1	General	3
2.2	Instructions for safe operation	4
3	About the system	5
3.1	Indoor unit	5
3.1.1	Indoor unit display	5
3.2	About the wireless LAN	5
3.2.1	Precautions when using the wireless LAN	5
3.2.2	Basic parameters	5
3.3	About the user interface	5
3.3.1	Components: Wireless remote control	6
3.3.2	To operate the wireless remote control	6
4	Before operation	6
4.1	To insert the batteries	6
4.2	To mount the wireless remote control holder	6
4.3	The clock setting	6
4.3.1	To set the clock	6
4.4	To turn on the power supply	7
4.5	Brightness of the indoor unit display	7
4.5.1	To set the brightness of the indoor unit display	7
4.6	To change indoor unit position setting	7
5	Operation	7
5.1	Operation range	7
5.2	Operation mode and temperature setpoint	8
5.2.1	To start/stop operation mode and to set the temperature	8
5.3	Smart auto	8
5.3.1	To start/stop Smart Auto function	8
5.4	ON/OFF Contact	8
5.5	Hot air preference	9
5.5.1	To start/stop Hot air preference	9
5.6	Temperature limit	9
5.6.1	To set temperature limit	9
5.7	Airflow rate	10
5.7.1	To adjust the airflow rate	10
5.8	Airflow direction	10
5.8.1	To adjust vertical airflow direction	10
5.8.2	To adjust horizontal airflow direction	10
5.8.3	To use 3D airflow direction	10
5.9	Comfort airflow and Intelligent eye operation	10
5.9.1	Comfort airflow operation	10
5.9.2	Intelligent eye operation	11
5.9.3	To start/stop Comfort and Intelligent eye operation	11
5.10	Powerful operation	11
5.10.1	To start/stop Powerful operation	11
5.11	Econo and Outdoor unit quiet operation	12
5.11.1	Econo operation	12
5.11.2	Outdoor unit quiet operation	12
5.11.3	To start/stop Econo and Outdoor unit quiet operation	12
5.12	Flash Streamer (air cleaning) operation	12
5.12.1	To start/stop Flash Streamer (air cleaning) operation	12
5.13	OFF/ON timer operation	12
5.13.1	24 hour clock OFF/ON timer setting	12
5.13.2	12 hour countdown OFF/ON timer setting	13
5.14	Weekly timer operation	13
5.14.1	To set Weekly timer operation	14
5.14.2	To copy reservations	14
5.14.3	To confirm reservations	14
5.14.4	To deactivate and reactivate Weekly timer operation	15

5.14.5	To delete reservations	15
5.15	Wireless LAN connection	15
5.15.1	Precautions when using the wireless LAN	15
5.15.2	To install the ONECTA app	15
5.15.3	To set the wireless connection	15

6 Energy saving and optimum operation 16

7 Maintenance and service 17

7.1	Overview: Maintenance and service	17
7.2	To clean the indoor unit and wireless remote control	17
7.3	To clean the front panel	17
7.4	To open the front panel	17
7.5	To clean the air filters	18
7.6	To clean the titanium apatite deodorising filter and the silver particle filter (Ag-ion filter)	18
7.7	To replace the titanium apatite deodorising filter and the silver particle filter (Ag-ion filter)	18
7.8	To close the front panel	18
7.9	To remove the front panel	19
7.10	To take following items into account before a long idle period ..	19
7.11	About the air filters	19

8 Troubleshooting 19

8.1	Troubleshooting for wireless LAN connection	20
-----	---	----

9 Disposal 20

1 About the documentation

1.1 Product code

CTXA15E, FTXA20E, FTXA25E, FTXA35E, FTXA42E, FTXA50E

1.2 About this document



WARNING

This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.

Children SHALL NOT play with the appliance.

Cleaning and user maintenance SHALL NOT be made by children without supervision.

Thank you for purchasing this product. Please:

- Keep the documentation for future reference.

Target audience

End users



INFORMATION

This appliance is intended to be used by expert or trained users in shops, in light industry, and on farms, or for commercial and household use by lay persons.

Documentation set

This document is part of a documentation set. The complete set consists of:

General safety precautions:

- Safety instructions that you must read before operating your system
- Format: Digital files on <https://www.daikin.eu>. Use the search function 🔍 to find your model.

- **Installer reference guide:**
 - Preparation of the installation, good practices, reference data, ...
 - Format: Digital files on <https://www.daikin.eu>. Use the search function 🔍 to find your model.
- **User reference guide:**
 - Detailed step-by-step instructions and background information for basic and advanced usage
 - Format: Digital files on <https://www.daikin.eu>. Use the search function 🔍 to find your model.
- **Installation manual:**
 - Installation instructions
 - Format: Digital files on <https://www.daikin.eu>. Use the search function 🔍 to find your model.
- **Operation manual:**
 - Quick guide for basic usage
 - Format: Paper (inside the indoor unit packaging)

Latest revisions of the supplied documentation may be available on the regional Daikin website or via your installer.

Scan the QR code below to find the full documentation set and more information about your product on the Daikin website.



The original instructions are written in English. All other languages are translations of the original instructions.

1.2.1 Meaning of warnings and symbols

	DANGER Indicates a situation that results in death or serious injury.
	DANGER: RISK OF ELECTROCUTION Indicates a situation that could result in electrocution.
	DANGER: RISK OF BURNING/SCALDING Indicates a situation that could result in burning/scalding because of extreme hot or cold temperatures.
	DANGER: RISK OF EXPLOSION Indicates a situation that could result in explosion.
	WARNING Indicates a situation that could result in death or serious injury.
	WARNING: FLAMMABLE MATERIAL
	WARNING: MILDLY FLAMMABLE MATERIAL The refrigerant inside this unit is mildly flammable.
	CAUTION Indicates a situation that could result in minor or moderate injury.
	NOTICE Indicates a situation that could result in equipment or property damage.
	INFORMATION Indicates useful tips or additional information.

Symbols used on the unit:

Symbol	Explanation
	Before installation, read the installation and operation manual, and the wiring instruction sheet.

Symbol	Explanation
	Before performing maintenance and service tasks, read the service manual.
	For more information, see the installer and user reference guide.
	The unit contains rotating parts. Be careful when servicing or inspecting the unit.

Symbols used in the documentation:

Symbol	Explanation
	Indicates a figure title or a reference to it. Example: "Fig 1-3 Figure title" means "Figure 3 in chapter 1".
	Indicates a table title or a reference to it. Example: "Table 1-3 Table title" means "Table 3 in chapter 1".

2 User safety instructions

Always observe the following safety instructions and regulations.

2.1 General



WARNING

If you are NOT sure how to operate the unit, contact your installer.



WARNING

This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.

Children SHALL NOT play with the appliance.

Cleaning and user maintenance SHALL NOT be made by children without supervision.



WARNING

To prevent electrical shocks or fire:

- Do NOT rinse the unit.
- Do NOT operate the unit with wet hands.
- Do NOT place any objects containing water on the unit.



CAUTION

- Do NOT place any objects or equipment on top of the unit.
- Do NOT sit, climb or stand on the unit.

- Units are marked with the following symbol:



This means that electrical and electronic products may NOT be mixed with unsorted household waste. Do NOT try to dismantle the system yourself: dismantling the system, treatment of the refrigerant, of oil and of other parts MUST be done by an authorised installer and MUST comply with applicable legislation.

Units MUST be treated at a specialised treatment facility for reuse, recycling and recovery. By ensuring this product is disposed of correctly, you will help to prevent potential negative consequences for the environment and human health. For more information, contact your installer or local authority.

2 User safety instructions

- Batteries are marked with the following symbol:



This means that the batteries may NOT be mixed with unsorted household waste. If a chemical symbol is printed beneath the symbol, this chemical symbol means that the battery contains a heavy metal above a certain concentration.

Possible chemical symbols are: Pb: lead (>0.004%).

Waste batteries MUST be treated at a specialised treatment facility for reuse. By ensuring waste batteries are disposed of correctly, you will help to prevent potential negative consequences for the environment and human health.

2.2 Instructions for safe operation



A2L WARNING: MILDLY FLAMMABLE MATERIAL

The refrigerant inside this unit is mildly flammable.



CAUTION

The indoor unit contains radio equipment, minimum separation distance between the radiating part of the equipment and the user is 10 cm.



CAUTION

Do NOT insert fingers, rods or other objects into the air inlet or outlet. When the fan is rotating at high speed, it will cause injury.



WARNING

This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.

Children SHALL NOT play with the appliance.

Cleaning and user maintenance SHALL NOT be made by children without supervision.



WARNING

- Do NOT modify, disassemble, remove, reinstall or repair the unit yourself as incorrect dismantling or installation may cause an electrical shock or fire. Contact your dealer.
- In case of accidental refrigerant leaks, make sure there are no naked flames. The refrigerant itself is entirely safe, non-toxic and mildly flammable, but it will generate toxic gas when it accidentally leaks into a room where combustible air from fan heaters, gas cookers, etc. is present. Always have qualified service personnel confirm that the point of leakage has been repaired or corrected before resuming operation.



CAUTION

ALWAYS use the wireless remote control or other user interface (if applicable) to adjust the position of the flaps and louvers. When the flaps and louvers are swinging and you move them forcibly by hand, the mechanism will break.



CAUTION

NEVER expose little children, plants or animals directly to the airflow.



WARNING

Do NOT place a flammable spray bottle near the air conditioner and do NOT use sprays near the unit. Doing so may result in a fire.



CAUTION

Do NOT operate the system when using a room fumigation-type insecticide. Chemicals could collect in the unit, and endanger the health of people who are hypersensitive to chemicals.



WARNING

- The refrigerant inside the unit is mildly flammable, but normally does NOT leak. If the refrigerant leaks in the room and comes in contact with fire from a burner, a heater, or a cooker, this may result in fire, or the formation of a harmful gas.
- Turn OFF any combustible heating devices, ventilate the room, and contact the dealer where you purchased the unit.
- Do NOT use the unit until a service person confirms that the part from which the refrigerant leaked has been repaired.



WARNING

- Do NOT pierce or burn refrigerant cycle parts.
- Do NOT use cleaning materials or means to accelerate the defrosting process other than those recommended by the manufacturer.
- Be aware that the refrigerant inside the system is odourless.



WARNING

The appliance shall be stored so as to prevent mechanical damage and in a well-ventilated room without continuously operating ignition sources (e.g. open flames, an operating gas appliance, or an operating electric heater). The room size shall be as specified in the General safety precaution.



DANGER: RISK OF ELECTROCUTION

To clean the air conditioner or air filter, be sure to stop operation and turn all power supplies OFF. Otherwise, an electrical shock and injury may result.



CAUTION

After a long use, check the unit stand and fitting for damage. If damaged, the unit may fall and result in injury.



WARNING

Be careful with ladders when working in high places.



WARNING

Improper detergents or cleaning procedure may cause damage on plastic components or water leakage. Splashed detergent on electric components, such as motors, may cause failure, smoke or ignition.



DANGER: RISK OF ELECTROCUTION

Before cleaning, be sure to stop the operation, turn the breaker OFF or pull out the supply cord. Otherwise, an electrical shock and injury may result.



WARNING

Stop operation and shut OFF the power if anything unusual occurs (burning smells etc.).

Leaving the unit running under such circumstances may cause breakage, electrical shock or fire. Contact your dealer.



WARNING

If the supply cord is damaged, it MUST be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

3 About the system



A2L

WARNING: MILDLY FLAMMABLE MATERIAL

The refrigerant inside this unit is mildly flammable.


CAUTION

The indoor unit contains radio equipment, minimum separation distance between the radiating part of the equipment and the user is 10 cm.


NOTICE

Do NOT use the system for other purposes. In order to avoid any quality deterioration, do NOT use the unit for cooling precision instruments, food, plants, animals, or works of art.

3.1 Indoor unit


CAUTION

Do NOT insert fingers, rods or other objects into the air inlet or outlet. When the fan is rotating at high speed, it will cause injury.



INFORMATION

The sound pressure level is less than 70 dBA.


WARNING

- Do NOT modify, disassemble, remove, reinstall or repair the unit yourself as incorrect dismantling or installation may cause an electrical shock or fire. Contact your dealer.
- In case of accidental refrigerant leaks, make sure there are no naked flames. The refrigerant itself is entirely safe, non-toxic and mildly flammable, but it will generate toxic gas when it accidentally leaks into a room where combustible air from fan heaters, gas cookers, etc. is present. Always have qualified service personnel confirm that the point of leakage has been repaired or corrected before resuming operation.

3.1.1 Indoor unit display



- a ON/OFF button
- b Signal receiver
- c Timer lamp (orange)
- d Intelligent eye lamp (green)
- e Wireless adapter ON/OFF button

ON/OFF button

If the wireless remote control (user interface) is missing, you can use the ON/OFF button on the indoor unit to start/stop operation. When operation is started using this button, the following settings are used:

- Operation mode = Automatic
- Temperature setting = 25°C
- Airflow rate = Automatic

3.2 About the wireless LAN

For detailed specifications, installation instructions, setting methods, FAQ, declaration of conformity and the latest version of this manual, visit app.daikineurope.com.


INFORMATION: Declaration of conformity

Daikin Industries Czech Republic s.r.o. declares that the radio equipment type inside of this unit is in compliance with Directive 2014/53/EU.

3.2.1 Precautions when using the wireless LAN

Do NOT use near:

- Medical equipment.** E.g. persons using cardiac pacemakers or defibrillators. This product may cause electromagnetic interference.
- Auto-control equipment.** E.g. automatic doors or fire alarm equipment. This product may cause faulty behaviour of the equipment.
- Microwave oven.** It may affect wireless LAN communications.

3.2.2 Basic parameters

Parameter	Value
Frequency range	2400 MHz~2483.5 MHz
Radio protocol	IEEE 802.11b/g/n
Radio frequency channel	1~13
Output power	13 dBm
Effective radiated power	15 dBm (11b) / 14 dBm (11g) / 14 dBm (11n)
Power supply	DC 14 V / 100 mA

3.3 About the user interface

Wireless remote control

INFORMATION

The indoor unit is delivered with the wireless remote control as the user interface. This manual describes only operation with this user interface. If another user interface is connected, refer to the operation manual of the connected user interface.


- Direct sunlight.** Do NOT expose the wireless remote control to direct sunlight.
- Dust.** Dust on the signal transmitter or receiver will reduce sensitivity. Wipe off dust with a soft cloth.
- Fluorescent lights.** Signal communication might be disabled if fluorescent lamps are in the room. In that case, contact your installer.
- Other appliances.** If the wireless remote control signals operate other appliances, move the other appliances, or contact your installer.
- Curtains.** Make sure that curtains or other objects do NOT block the signal between the unit and the wireless remote control.


NOTICE

- Do NOT drop the wireless remote control.
- Do NOT let the wireless remote control get wet.

4 Before operation


3.3.1 Components: Wireless remote control



INFORMATION

Use (hold for 2 seconds) to open the front panel when you clean the air filters. See "7.4 To open the front panel" [p. 17].

3.3.2 To operate the wireless remote control



Note: Make sure that there are no obstacles within 500 mm under the infrared signal receiver. They may influence reception performance of the wireless remote control.

- 1 Aim the signal transmitter at the infrared signal receiver on the indoor unit (maximum distance for communication is 7 m).

Result: When the indoor unit receives a signal from the wireless remote control, you will hear a sound:


Sound	Description
Beep-beep	Operation starts.
Beep	Setting changes.
Long beep	Operation stops.

4 Before operation

4.1 To insert the batteries

The batteries will last for about 1 year.


- 1 Remove the front cover.
- 2 Insert both batteries at once.
- 3 Put back the front cover.



INFORMATION

- Low energy of battery is indicated by flashing of LCD display.
- ALWAYS replace both batteries at once.

4.2 To mount the wireless remote control holder



- 1 Choose a place where the signals reach the unit.
- 2 Attach the holder with screws to the wall or a similar location.
- 3 Hang the wireless remote control on the holder.

4.3 The clock setting

If the indoor unit's internal clock is NOT set to the correct time, the ON timer, OFF timer and weekly timer will NOT operate correctly. The clock must be set again:


- After a circuit breaker has turned the unit OFF.
- After a power failure.
- After replacing batteries in the wireless remote control.

4.3.1 To set the clock

Note: If the time is NOT set, MON, , and 0:00 blink.

- 1 Press .


Result: MON and blink



2 Press or to set the current day of the week.

3 Press .

Result: blinks.




4 Press or to set the correct time.

Note: Holding down or increases or decreases the time setting rapidly.

5 Press .

Result: Setting is complete. blinks.



4.4 To turn on the power supply

1 Turn the circuit breaker on.

Result: The flap of the indoor unit will open and close to set the reference position.


4.5 Brightness of the indoor unit display

Adjust the brightness of the indoor unit display as desired, or turn OFF the display.

4.5.1 To set the brightness of the indoor unit display

1 Press for at least 2 seconds.

Result: The menu appears on the display. is blinking.



2 Press .

3 Press or to change the setting as follows:



...is blinking	Brightness is...
H	High
L	Low
of	Off

4 To confirm the selected setting, press .

Result: The brightness setting is changed.

Note: The display automatically returns to the default screen after 60 seconds. To return to the default screen sooner, press .

4.6 To change indoor unit position setting


Set the indoor unit position to avoid direct airflow to walls.

1 Press for at least 2 seconds.

Result: The menu appears on the display.


2 Press or to change the menu to 5.

Result: The menu 5 appears on the display. 5 blinks.



3 Press to select the menu.

Result: blinks.



4 Press or to change the setting as follows:



If the unit is...	Symbol	Blinks	Result
In the middle of the wall (factory default setting)		1	
≤500 mm from the wall on right		2	
≤500 mm from the wall on left		3	

Result: The airflow range will be adjusted to avoid direct contact with the wall.

5 Operation



INFORMATION

The indoor unit is delivered with the wireless remote control as the user interface. This manual describes only operation with this user interface. If another user interface is connected, refer to the operation manual of the connected user interface.

5.1 Operation range

Use the system in the following temperature and humidity ranges for safe and effective operation.

	Cooling and dry-ing ^{(a)(b)}	Heating ^(a)
Outdoor temperature	−10~46°C DB	−15~24°C DB
Indoor temperature	18~32°C DB	10~30°C DB
Indoor humidity	≤80% ^(b)	—

5 Operation

- ^(a) A safety device might stop the operation of the system if the unit runs outside its operation range.
- ^(b) Condensation and water dripping might occur if the unit runs outside its operation range.

5.2 Operation mode and temperature setpoint

When. Adjust the system operation mode and set the temperature when you want to:

- Heat up or cool down a room
- Blow air in a room without heating or cooling
- Decrease the humidity in a room

What. The system operates differently, depending on the user selection.

Setting	Description
Automatic	The system cools down or heats up a room to the temperature setpoint. It automatically switches between cooling and heating if necessary.
Drying	The system decreases the humidity in a room.
Heating	The system heats up a room to the temperature setpoint.
Cooling	The system cools down a room to the temperature setpoint.
Fan	The system only controls the airflow (airflow rate and airflow direction). The system does NOT control the temperature.

Additional info:

- Outside temperature.** The system's cooling or heating effect decreases when the outside temperature is too high or too low.
- Defrost operation.** During heating operation, frost might occur on the outdoor unit and decrease the heating capacity. In that case, the system automatically switches to defrosting operation to remove the frost. During defrosting operation, hot air is NOT blown from the indoor unit.
- Humidity sensor.** Control the humidity by decreasing the humidity during cooling process.

5.2.1 To start/stop operation mode and to set the temperature

ON: Unit is operating.

A: Operation mode = Automatic

: Operation mode = Drying

: Operation mode = Cooling

: Operation mode = Heating

: Operation mode = Fan only

27.0°C: Shows the set temperature.

- Press **Mode** one or more times to select the operation mode.

Result: The mode will be set as follows:



- Press **Power** to **start** operation.

Result: **ON** and the selected mode are displayed on the LCD.

- Press **Temp** or **Temp** one or more times to lower or raise the **temperature**.

Cooling operation	Heating operation	Automatic operation	Drying or Fan only operation
18~32°C	10~30°C	18~30°C	—

Note: When using **drying** or **fan only** mode, you cannot adjust the temperature.

- Press **Power** to **stop** operation.

Result: **ON** disappears from the LCD. The operation lamp goes off.

5.3 Smart auto

This feature automatically adjusts the temperature setpoint to keep you comfortable, based on your personal preferences.

Over time, the unit learns how you like the temperature in different situations and uses this knowledge to adjust settings automatically. By learning your habits, this feature reduces how often you need to manually adjust the temperature to reach a comfortable room setting.

It also helps reduce discomfort caused by changes in outdoor weather, such as cooler nights or seasonal shifts.



INFORMATION

Smart auto function works only when the unit is operating in **automatic mode**.

5.3.1 To start/stop Smart Auto function



INFORMATION

You can switch this function off to take full control of the temperature setpoint.

- On the home screen, press **Smart Auto** for at least 2 seconds.

Result: The menu **SA** appears. **SA** is blinking.


- Navigate to Smart auto - SA setting **2** by pressing **Up** or **Down**.
- Press **Enter** to enter setting.

Result: Setting symbol (**on** or **of**) is blinking.

- of**: function is OFF
- on** (factory setting): function is ON

- Change setting **on** ↔ **of** by pressing **Up** or **Down**. Press **Enter** to confirm.

Result: Setting confirmed, you are in setting menu, **2** is blinking.



Note: The display automatically returns to the home screen after 60 seconds. To return to the default screen sooner, press **Cancel**.

5.4 ON/OFF Contact

This function requires purchase and installation of the KER303A option.

Use this function to automatically stop the unit by an external dry contact signal (e.g. window sensor or door card key).

This function helps reduce unnecessary energy consumption when a window or door is open or when the room is unoccupied.

The unit stops operation according to the status of the external contact.

**INFORMATION**

This function uses a dry contact and wire harness, which must be installed by a qualified installer.

- The delay time (0 – factory setting / 1 / 2 / 3 / 5 minutes) and restart mode are configured by the installer according to your preferences.
- When this function is active, it may prevent the unit to operate even if an operation command is given from the remote controller or the ONECTA app.

Behaviour when the ON/OFF contact is active

When the ON/OFF contact function is enabled, the system behaviour changes according to the contact status.

Example (window closed → window opened)

- While the window is **closed**, the unit can operate normally.
- When the window is **opened**, the delay timer starts.
- After the delay time has elapsed, the unit stops operation and goes to standby.
- While the window is open:
 - The ON/OFF command from the remote controller or the ONECTA app is disabled.
 - Other settings, such as **setpoint**, **mode**, or **fan speed**, can still be changed, but they will only take effect after the unit restarts.

Restart mode setting

The restart mode determines how the unit behaves after the window is closed again.

Manual Restart

- The unit does not restart automatically.
- When the window is closed, operation must be started manually by pressing the ON command using the remote controller or ONECTA app.

Auto Restart

- The unit starts automatically in the last operating mode after the window is closed.

Information

- If three short beeps are heard and the operation LED flashes two times, operation is blocked by the ON/OFF contact.
- Once the window is closed, the unit either restarts automatically or remains stopped, depending on the selected restart mode.

**NOTICE**

If you want to change the settings (delay time or restart mode), contact your installer.

5.5 Hot air preference

Use this function to enjoy a more comfortable heating experience while still setting the airflow rate manually.

**INFORMATION**

- In heating mode, the airflow rate will temporarily lower to prevent cold drafts. Once the air warms up, the unit will continue operating at your selected airflow rate.
- Activating this function may slightly reduce heating performance in very cold conditions or lower efficiency.

5.5.1 To start/stop Hot air preference

- On the home screen, press for at least 2 seconds.

Result: Setting menu appears. is blinking.

- Navigate to the Hot air preference – **HAP** setting by pressing or .

Result: is blinking.

- Press to enter the **HAP** setting.


Result: Setting symbol (**on** or **of**) is blinking.

- of** (factory setting): function is OFF

- on**: function is ON

- Change setting **on** ↔ **of** by pressing or . Press to confirm.

Result: Setting confirmed, you are in setting menu, is blinking.



Note: The display automatically returns to the home screen after 60 seconds. To return to the default screen sooner, press .

5.6 Temperature limit

This function is designed to limit the temperature setpoint that you can select, helping reduce energy consumption and avoid unnecessary over-cooling or over-heating.

**INFORMATION**

- The temperature limit defines the minimum cooling and maximum heating setpoints that can be set using the wireless remote control or the ONECTA app.
- Limits are configured separately for wireless remote control and ONECTA app.
- Once limits are set, both heating, cooling and automatic setpoints will be restricted accordingly.

Behaviour when the Temperature limit is active

When the temperature limit function is enabled, the system behaviour changes to ensure consistent operation within the defined limits.

Example:

- If the cooling lower limit is set to **20 °C**, the cooling setpoint range will be **20–32 °C**.
- If the heating higher limit is set to **28 °C**, the heating setpoint range will be **10–28 °C**.
- In **Automatic mode**, the setpoint range will be **20–28 °C**.

Factory default settings:

- Cooling lower limit: 18 °C
- Heating higher limit: 30 °C

**INFORMATION**


- The temperature limit function cannot be fully deactivated. However, restoring the limits to the factory default values allows unrestricted operation within the unit's full setpoint range.
- For proper operation, make sure the same temperature limits are configured both on the remote controller and in the ONECTA app.
- Depending on the selected temperature limits, the unit's heating or cooling capacity may be reduced due to the restricted setpoint range.

5.6.1 To set temperature limit

- Press + to enter the setting.

Result: The setting SC 001 appears.

- Use to navigate to LS (temperature limit setting) 005.




- Press to enter the temperature limit setting.

5 Operation

Result: Setting  for cooling lower limit appears.

- Use  to select the desired cooling lower limit.
- Press  to confirm and move to setting  of heating upper limit.
- Use  to select the desired heating upper limit temperature.
- Press  to confirm and exit the temperature range setting mode, while pointing it towards the indoor unit.

Result: The lower limit for cooling and the upper limit for heating are confirmed. Screen returns to the setting menu.



Note: The display automatically returns to the home screen after 60 seconds of inactivity. To exit earlier, press .

Note: If more than 60 seconds pass after setting the cooling limit, the original cooling value will be restored, and the heating limit setting will not be applied.

5.7 Airflow rate

- Press  to choose:

	5 airflow rate levels, from "≡" to "▮"
	Automatic airflow rate operation
	Indoor unit quiet operation. When the airflow rate is set to "▮", the noise from the unit will be reduced.



INFORMATION

- If the unit reaches the temperature setpoint in cooling or heating mode, the fan will stop operating.
- When using drying operation mode, you CANNOT adjust the airflow rate setting.

5.7.1 To adjust the airflow rate

- Press  to change the airflow setting as follows:



5.8 Airflow direction

When. Adjust the airflow direction as desired.

What. The system directs the airflow differently, depending on the user selection (swinging or fixed position). It does so by moving horizontal blades (flaps) or vertical blades (louvers).

Setting	Airflow direction
 Vertical automatic swing	Moves up and down.
 Horizontal automatic swing	Moves from side to side.
 3-D airflow direction	Moves alternately up and down and from side to side
 [-]	Stays in a fixed position.



CAUTION

ALWAYS use the wireless remote control or other user interface (if applicable) to adjust the position of the flaps and louvers. When the flaps and louvers are swinging and you move them forcibly by hand, the mechanism will break.

The movable range of the flap varies according to the operation mode. The flap will stop at the upper position when the airflow rate is changed to low during the up and down swing setting.

5.8.1 To adjust vertical airflow direction

- Press .

Result:  appears on the LCD. The flaps (horizontal blades) will begin to swing.

- To use fixed position, press  when the flaps reach the desired position.

Result:  disappears from the LCD. The flaps will stop moving.

5.8.2 To adjust horizontal airflow direction

- Press .

Result:  appears on the LCD. The louvers (vertical blades) will begin to swing.

- To use fixed position, press  when the louvers reach the desired position.

Result:  disappears from the LCD. The louvers will stop moving.



INFORMATION

When the unit is installed in a corner of a room, the direction of the louvers should be facing away from the wall. Efficiency will drop if a wall blocks the air.

5.8.3 To use 3D airflow direction

- Press  and .

Result:  and  appear on the LCD. The flaps (horizontal blades) and louvers (vertical blades) will begin to swing.

- To use fixed position, press  and  when the flaps and louvers reach the desired position.


Result:  and  disappear from the LCD. The flaps and the louvers will stop moving.

5.9 Comfort airflow and Intelligent eye operation

You can use Comfort and Intelligent eye operation separately, or combine them.

5.9.1 Comfort airflow operation


The unit will automatically change the direction of the airflow to heat up or cool down the room more effectively. Direct airflow from the unit will be less noticeable.



- a Flap position in cooling and dry operation
- b Flap range in heating operation (vertical airflow ON)
- c Flap position in heating operation (vertical airflow OFF)


In cooling and drying

The airflow direction will change to spread the air along the ceiling.



In heating

The airflow direction will change to spread the air along the floor. The unit detects the room and floor temperature and automatically selects 1 of the 3 airflow directions.



INFORMATION

If you want to deactivate the Vertical airflow function (e.g. in case there is furniture or another object under the unit), refer to "To turn ON/OFF vertical airflow function" [p. 11]. If the Vertical airflow function is deactivated, the airflow will be set to downward direction.



INFORMATION

Powerful and Comfort airflow operation CANNOT be used at the same time. The last selected function takes priority. If the vertical automatic swing is selected, Comfort airflow operation will be cancelled.


To turn ON/OFF vertical airflow function

- 1 Press for at least 2 seconds.

Result: The menu appears on the display.

- 2 Press or to change the menu screen.

Result: The menu appears on the display.



- 3 Press to change the setting.

- 4 Press or to change the setting.

...is blinking	Vertical airflow function is...
on	turned ON
of	turned OFF

- 5 To confirm the selected setting press .

Note: The display automatically returns to the default screen after 60 seconds. To return to the default screen sooner, press .

5.9.2 Intelligent eye operation

The system detects movement in the room and automatically adjusts the airflow direction and temperature in order to avoid direct contact with people. If no movement is detected for 20 minutes, the system switches to energy saving operation:

About the Intelligent eye sensor



NOTICE

- Do NOT hit or push the Intelligent eye sensor. Doing so may lead to malfunction.
- Do NOT place large objects near the Intelligent eye sensor.



INFORMATION

Night set mode (OFF timer) CANNOT be used at the same time with Intelligent eye operation.

- Detection range.** Up to 9 m.
- Detection sensitivity.** Changes according to location, the number of persons in the room, temperature range, etc.
- Detection mistakes.** The sensor may mistakenly detect pets, sunlight, moving curtains, etc.

5.9.3 To start/stop Comfort and Intelligent eye operation

- 1 Press one or more times.

Result: The setting will change as follows:



Display	Operation
	Comfort airflow
	Intelligent eye
	Comfort airflow and Intelligent eye
—	Both deactivated

Note: If there are people close to the front of the indoor unit or there are too many people, use both operations at the same time.

- 2 To stop operation, press until both symbols disappear from the LCD.

5.10 Powerful operation

This operation quickly maximizes the cooling/heating effect in any operation mode. You can get the maximum capacity.



INFORMATION

Powerful operation CANNOT be used together with Econo, Comfort airflow and Outdoor unit quiet operation. The last selected function takes priority.

Powerful operation will NOT increase the capacity of the unit if it already operates at maximum capacity.

5.10.1 To start/stop Powerful operation

- 1 Press to start.

Result: is displayed on the LCD. Powerful operation runs for 20 minutes; after that, operation returns to the previously set mode.

- 2 Press to stop.

Result: disappears from the LCD.

Note: Powerful operation can be set only when the unit is running. If you press or if you change operation mode, operation will be cancelled; disappears from the LCD.

5 Operation

5.11 Econo and Outdoor unit quiet operation

5.11.1 Econo operation

This is a function which enables efficient operation by limiting the maximum power consumption value. This function is useful for cases in which attention should be paid to ensure a circuit breaker will not trip when the product runs alongside other appliances.

INFORMATION

- Powerful and Econo operation CANNOT be used at the same time. The last selected function takes priority.
- Econo operation reduces power consumption of the outdoor unit by limiting the rotation speed of the compressor. If power consumption is already low, Econo operation will NOT further reduce power consumption.

5.11.2 Outdoor unit quiet operation

Use Outdoor unit quiet operation when you want to decrease the noise level of the outdoor unit. **Example:** At night.

INFORMATION

- Powerful and Outdoor unit quiet operation CANNOT be used at the same time. The last selected function takes priority.
- This function is only available in Automatic, Cooling, and Heating operation.
- Outdoor unit quiet operation limits the rotation speed of the compressor. If the rotation speed of compressor is already low, Outdoor unit quiet operation will NOT further reduce the compressor rotation speed.

5.11.3 To start/stop Econo and Outdoor unit quiet operation

- Press  one or more times.

Result: The setting will change as follows.



Display	Operation
	Econo
	Outdoor unit quiet
	Econo and Outdoor unit quiet
—	Both deactivated

- To stop operation, press  until both symbols disappear from the LCD.

Note: Econo operation can be only set when the unit is running. Pressing  cancels the setting and  disappears from the LCD.

Note:  remains on the LCD, even if you turn off the unit using the wireless remote control or indoor unit ON/OFF switch.

5.12 Flash Streamer (air cleaning) operation

Streamer generates a high-speed electron stream with a high oxidizing power, reducing bad odours. Together with the titanium apatite deodorising filter and the air filters, this function cleans the air in the room.

INFORMATION

- The high-speed electrons are generated and go away inside the unit to ensure safe operation.
- The Streamer discharge may generate a fizzing sound.
- If the airflow becomes weak, the Streamer discharge may stop temporarily to prevent ozone smell.

5.12.1 To start/stop Flash Streamer (air cleaning) operation

Prerequisite: Make sure the unit is operating ( is displayed on the wireless remote control LCD).

- Press .

Result:  is displayed on the LCD and the air in the room is cleaned when the unit is operating.

- To stop operation, press .

Result:  disappears from the LCD and operation stops.

5.13 OFF/ON timer operation

Timer functions are useful for automatically switching the air conditioner off/on at night or in the morning. You can also use OFF timer and ON timer in combination.

There are two types of OFF/ON timer setting:

- 24 hour clock OFF/ON timer** (default). The unit will stop/start operating at the set time. **Example:** The ON timer is set to 13:30, the unit will start operating at 13:30.
- 12 hour countdown OFF/ON timer.** The unit will stop/start operating after the set number of hours. **Example:** The ON timer is set at 10:30 to 3 hours, the unit will start operating at 13:30.

Note: It is possible to combine both timer setting types.

INFORMATION

Program the timer again in case of:

- A breaker has turned the unit off.
- A power failure.
- After replacing batteries in the wireless remote control.

INFORMATION

The clock MUST be set correctly before using any timer functions. Refer to "4.3.1 To set the clock" [p 6].

5.13.1 24 hour clock OFF/ON timer setting

To start/stop OFF timer operation

- Press  to start.

Result:  is displayed on the LCD and OFF blinks.  and the day of the week disappear from the LCD.



- Press  or  to change the time setting.
- Press  again.

Result: OFF and the set time are displayed on the LCD.

Result: The timer lamp lights up.

INFORMATION

Each time  or  is pressed, the time setting advances by 10 minutes. Holding the button down will change the setting rapidly.

- To stop operation, press .

Result:  and OFF disappear from the LCD and the timer lamp goes off.  and the day of the week are displayed on the LCD.

INFORMATION

When you set the ON/OFF timer, the time setting is stored in the memory. When the wireless remote control batteries are replaced, the remote control keeps the time setting for the ON/OFF timer, but the timer is cancelled.


Night set mode

When the OFF timer is set, the air conditioner automatically adjusts the temperature setting (0.5°C up in cooling, 2.0°C down in heating) to prevent excessive cooling/heating and ensure a comfortable sleeping temperature.

To start/stop ON timer operation

- 1 Press **On** to start.

Result: **6:00** is displayed on the LCD and **ON** blinks. ☉ and the day of the week disappear from the LCD.



- 2 Press **Select** or **Select** to change the time setting.
- 3 Press **On** again.

Result: **ON** and the set time are displayed on the LCD. The timer lamp lights up.

INFORMATION

Each time **Select** or **Select** is pressed, the time setting advances by 10 minutes. Holding the button down will change the setting rapidly.

- 4 To stop operation, press **Cancel**.

Result: **6:00** and **ON** disappear from the LCD and the timer lamp goes off. ☉ and the day of the week are displayed on the LCD.

To combine OFF timer and ON timer

- 1 To set the timers, refer to "To start/stop OFF timer operation" ▶ 12] and "To start/stop ON timer operation" ▶ 13].

Result: **OFF** and **ON** are displayed on the LCD.

Example:

Display	Current time	Set while...	Operation
OFF 7:00 ON 14:00	6:00	the unit is operating.	Stops at 7:00 and starts at 14:00.
		the unit is NOT operating.	Starts at 14:00.


Note: If the timer setting is active, the current time is NOT displayed on the LCD.

5.13.2 12 hour countdown OFF/ON timer setting


To start/stop countdown OFF/ON timer operation

- 1 Press and hold **Off** or **On** for about 5 seconds; when ▲ blinks, release the button.

Result:



For the OFF timer, **1hr** appears on the LCD and **OFF** blinks. ☉ and the day of the week disappear from the LCD.



For the ON timer, **1hr** appears on the LCD and **ON** blinks. ☉ and the day of the week disappear from the LCD.

- 2 Press **Select** or **Select** to change the time setting. The time can be set between 1~12 hours. Each pressing of the button increases or decreases the time setting by 1 hour.

- 3 Press **Off** or **On** to confirm the setting.

Result: **OFF** and/or **ON** and the set time are displayed on the LCD. The timer lamp lights up. The time displayed on the LCD will automatically count down by 1 hour for every hour that passes.

Example: If the OFF timer is set to 3 hours, the displayed time will change as follows: 3hr → 2hr → 1hr → blank (OFF)

- 4 To change the setting back to 24 hour OFF/ON timer, repeat step 1 when on the home screen when **OFF** and/or **ON** are NOT blinking.
- 5 To cancel the timer setting, press **Cancel**.

To combine the timer display modes

Different display modes (24 hour and 12 hour countdown OFF/ON timer) can be used for the OFF timer and ON timer simultaneously.

- 1 For setting, see "To start/stop OFF timer operation" ▶ 12], "To start/stop ON timer operation" ▶ 13] and "To start/stop countdown OFF/ON timer operation" ▶ 13].

Example:

Display	Current time	Set while...	Operation
OFF 3hr ON 6:00	22:00	the unit is operating.	Stops at 1:00 (3 hours after present time)
OFF 1:00 ON 8hr			Starts at 6:00. (8 hours after present time)
OFF 3hr ON 8hr			

Note: If the timer setting is active, the current time is NOT displayed on the LCD.

5.14 Weekly timer operation

INFORMATION

The following setting procedure is for the wireless remote control only. However, we recommend to perform the weekly timer setting using the ONECTA app. Refer to "5.15 Wireless LAN connection" ▶ 15] for more information.

With this operation, you can save up to 4 timer settings for each day of the week.

Example: Create a different setting from Monday to Friday and a different setting for weekends.

Day of the week	Setting example
Monday	<div> <div>1 ON</div> <div>2 OFF</div> <div>3 ON</div> <div>4 OFF</div> </div> <p>Make up to 4 settings.</p>
Tuesday~Friday	<div> <div>1 ON</div> <div>2 OFF</div> <div>3 ON</div> <div>4 OFF</div> </div> <p>Use the copy mode if the settings are the same as for Monday.</p>
Saturday	—
Sunday	<div> <div>1 ON</div> <div>2 OFF</div> <div>3 OFF</div> <div>4 ON</div> </div> <p>Make up to 4 settings.</p>

- **ON-ON-ON-ON setting.** Enables scheduling the operation mode and set temperature.
- **OFF-OFF-OFF-OFF setting.** Only the turn off time can be set for each day.

Note: Be sure to aim the wireless remote control at the indoor unit and check for a receiving tone when setting the Weekly timer operation.

5 Operation

i INFORMATION

The clock **MUST** be set correctly before using any timer functions. Refer to "4.3.1 To set the clock" [p. 6].

i INFORMATION

- Weekly timer and OFF/ON timer operation **CANNOT** be used at the same time. The OFF/ON timer operation takes priority. Weekly timer will be in standby, **⌚ WEEKLY** disappears from the LCD. When the OFF/ON timer is completed, the Weekly timer becomes active.
- The day of the week, OFF/ON timer mode, time and temperature (only for ON timer) can be set with the Weekly timer. Other settings are based on previous ON timer setting.

5.14.1 To set Weekly timer operation

- Press **⏏**.

Result: The day of the week and the reservation number of the current day are displayed.



- Press **Select** or **Select** to select the day of the week and the reservation number.

- Press **Next**.

Result: The day of the week is set. **⌚ WEEKLY** and ON blink.



- Press **Select** or **Select** to select the mode.

Result: The setting will change as follows:



Display	Feature
ON	ON timer
OFF	OFF timer
Blank	Deletes reservation

- Press **Next**.

Result: The OFF/ON timer mode is set. **⌚ WEEKLY** and the time blink.



Note: Press **Back** to return to the previous screen. If blank is selected, continue to step 9.

- Press **Select** or **Select** to select the time. The time can be set between 0:00~23:50 in 10-minute intervals.

- Press **Next**.

Result: The time is set and **⌚ WEEKLY** and the temperature blink.



Note: Press **Back** to return to the previous screen. If OFF timer is selected, continue to step 9.

- Press **Select** or **Select** to select the desired temperature.

Note: The set temperature for the weekly timer is displayed only when setting the weekly timer mode.

i INFORMATION

The temperature can be set between 10~32°C on the wireless remote control, however:

- in cooling and automatic operation mode, the unit will operate at minimum 18°C, even if is set to 10~17°C;
- in heating and automatic operation mode, the unit will operate at maximum 30°C, even if is set to 31~32°C.

- Press **Next**.

Result: The temperature and time are set for the ON timer. The time is set for the OFF timer. The timer lamp lights orange.

Result: A new reservation screen will appear.

- Repeat the previous procedure to set another reservation or press **⏏** to complete the setting.

Result: **⌚ WEEKLY** is displayed on the LCD.

Note: A reservation can be copied with the same settings to another day. Refer to "5.14.2 To copy reservations" [p. 14].

5.14.2 To copy reservations


A reservation can be copied to another day. The complete reservation of the selected day of the week will be copied.

- Press **⏏**.

- Press **Select** or **Select** to select the day of the week to be copied.

- Press **Copy**.


Result: The reservation of the selected day of the week will be copied.



- Press **Select** or **Select** to select the destination day.

- Press **Copy**.

Result: The whole reservation is copied to the selected day and the timer lamp lights orange.



Note: To copy to another day, repeat the procedure.

- Press **⏏** to complete the setting.

Result: **⌚ WEEKLY** is displayed on the LCD.

Note: To change the reservation setting after copying, refer to "5.14.1 To set Weekly timer operation" [p. 14].

5.14.3 To confirm reservations

You can confirm if all reservations are set to your needs.

- Press **⏏**.

Result: The day of the week and the reservation number of the current day are displayed.



- Press or to select the day of the week and reservation number to be confirmed and check the reservation details.

Note: To change the reservation setting, refer to "5.14.1 To set Weekly timer operation" [p. 14].

- Press to exit the confirmation mode.

5.14.4 To deactivate and reactivate Weekly timer operation

- To deactivate the Weekly timer, press while is displayed on the LCD.

Result: disappears from the LCD and the timer lamp goes off.

- To reactivate the Weekly timer, press again.

Result: The last set reservation mode will be used.

5.14.5 To delete reservations

To delete individual reservations

Use this function if you want to delete a single reservation setting.

- Press .

Result: The day of the week and the reservation number are displayed.

- Press or to select the day of the week to be deleted.

- Press .

Result: , ON, and OFF blink.

- Press or and select "blank".

Result: The setting will change as follows:



- Press .

Result: The selected reservation is deleted.

- Press to exit.

Result: Remaining reservations are active.

To delete a reservation for each day of the week

Use this function if you want to delete all reservation settings for one day of the week. This can be used in confirmation or setting mode.

- Press .
- Press or to select the day of the week to be deleted.
- Hold for about 5 seconds.

Result: All reservations for the selected day are deleted.

- Press to exit.

Result: Remaining reservations are active.

To delete all reservations

Use this function if you want to delete all reservations for all days of the week in one go. This procedure CANNOT be used in the setting mode.

- Hold for about 5 seconds while in the default display.

Result: All reservations will be deleted.

5.15 Wireless LAN connection

Simply connect your unit to your home network and download the app to change the thermostat, set temperature schedules, review your energy consumption and more.


For details on specifications, setting methods, FAQ, troubleshooting tips, visit app.daikineurope.com.



The customer is responsible for providing:

- Smartphone or tablet with minimum supported version of Android or iOS, specified on app.daikineurope.com.
- Internet line and communication device, such as a modem, router, etc.
- Wireless LAN access point
- Installed free ONECTA application

Note: If needed, the SSID number and the KEY are located on the unit or can be found in the accessory bag.



a Label with SSID number and password

5.15.1 Precautions when using the wireless LAN

Do NOT use near:

- Medical equipment.** E.g. persons using cardiac pacemakers or defibrillators. This product may cause electromagnetic interference.
- Auto-control equipment.** E.g. automatic doors or fire alarm equipment. This product may cause faulty behaviour of the equipment.
- Microwave oven.** It may affect wireless LAN communications.

5.15.2 To install the ONECTA app

- Go to Google Play (for Android devices) or the App Store (for iOS devices) and search for "ONECTA".
- Follow the directions on the screen to install the ONECTA app.



INFORMATION

Scan the QR code to download and install the ONECTA app on your mobile phone or tablet:



5.15.3 To set the wireless connection

There are two options to connect the wireless adapter to your home network.

- Use either Access Point mode (SSID and KEY) or the WPS button. Open the ONECTA app and follow the on-screen instructions.

For more information and FAQ, refer to app.daikineurope.com.

Note: Setting is done by the wireless remote control in the wireless LAN setting menu. During setting, always aim the wireless remote control at the infrared signal receiver on the unit.



INFORMATION

Make sure operation is stopped before setting the wireless connection. Connection CANNOT be made when the unit is in operation.

- Stop operation** before setting the wireless connection.

6 Energy saving and optimum operation


- Make sure the wireless router is close enough to the unit and nothing obstructs the signal.

Menu	Description
1	Connection status check
2	Connection using WPS button
3	Connection using Access Point mode
R	Reset to factory default
oFF	Wireless LAN OFF

To confirm the wireless LAN connection status

- Hold  for at least 5 seconds.

Result: The confirmation display (menu 1) appears.



- Press  to confirm the selection.

Result: "Beep" sound is heard when the unit receives signal.

- Check the indoor unit LED.

If operation LED...	...and timer LED...	...then wireless LAN is...
blinks	blinks	not connected
is off	blinks in 0.5 second interval	running and ready to connect to the home network via WPS button on the router.
is off	blinks in 1 second interval	<ul style="list-style-type: none"> connected to the home network via Access Point mode. or connected to the home network via WPS button on the router.

- Press  to exit the menu.

Result: The display will return to the default screen.

To reset the connection setting to the factory default


Reset the connection setting to the factory default in case you want to:

- disconnect the wireless LAN and the communication device (e.g. router) or smart device,
- repeat the setting if the connection was unsuccessful.

- On home screen menu, hold  for at least 5 seconds while the unit is not operating.

Result: The SP menu 1 appears. 1 is blinking.

- Change to the SP menu R by pressing  twice or  repeatedly.



- Hold  for at least 2 seconds to confirm the selection.

Result: R is blinking. The operation and timer LEDs blink simultaneously at 1-second intervals. The setting is reset to the factory default.

- Press  to exit the menu.

Result: The display will return to the default screen.

To turn off the wireless LAN connection

You can turn off the wireless connection using:

- the wireless adapter ON/OFF button on the unit,
- the user interface.

To use the wireless adapter ON/OFF switch

- Press the wireless adapter ON/OFF switch.

Result: The wireless adapter communication is OFF.

Note: Press the ON/OFF switch again to turn on the wireless adapter.


To use the user interface

If you want to turn off the wireless connection function:

- On home screen menu, press  for at least 5 seconds while the unit is not operating.

Result: The SP menu 1 appears. 1 is blinking.

- Change to the SP menu oFF by pressing  once or  repeatedly.



- Hold  for at least 2 seconds to confirm the selection.

Result: oFF is blinking. The operation and timer LEDs blink alternately at 1-second intervals. Communication is OFF.

- Press  to exit the menu.

Result: The display will return to the default screen.

6 Energy saving and optimum operation



INFORMATION

- Even if the unit is turned OFF, it consumes electricity.
- When the power turns back on after a power break, the previously selected mode will be resumed.



CAUTION

NEVER expose little children, plants or animals directly to the airflow.



NOTICE

Do NOT place objects that should NOT get wet below the unit. Condensation on the unit or refrigerant pipes, or drain blockage may cause dripping. **Possible consequence:** Objects under the unit can get dirty or damaged.



WARNING

Do NOT place a flammable spray bottle near the air conditioner and do NOT use sprays near the unit. Doing so may result in a fire.



CAUTION

Do NOT operate the system when using a room fumigation-type insecticide. Chemicals could collect in the unit, and endanger the health of people who are hypersensitive to chemicals.

7 Maintenance and service

7.1 Overview: Maintenance and service

The installer has to perform a yearly maintenance.

About the refrigerant

This product contains fluorinated greenhouse gases. Do NOT vent gases into the atmosphere.

Refrigerant type: R32

Global warming potential (GWP) value: 675



NOTICE

Maintenance **MUST** be done by an authorised installer or service agent.

We recommend performing maintenance at least once a year. However, applicable legislation might require shorter maintenance intervals.



WARNING

- The refrigerant inside the unit is mildly flammable, but normally does NOT leak. If the refrigerant leaks in the room and comes in contact with fire from a burner, a heater, or a cooker, this may result in fire, or the formation of a harmful gas.
- Turn OFF any combustible heating devices, ventilate the room, and contact the dealer where you purchased the unit.
- Do NOT use the unit until a service person confirms that the part from which the refrigerant leaked has been repaired.



WARNING

- Do NOT pierce or burn refrigerant cycle parts.
- Do NOT use cleaning materials or means to accelerate the defrosting process other than those recommended by the manufacturer.
- Be aware that the refrigerant inside the system is odourless.



WARNING

The appliance shall be stored so as to prevent mechanical damage and in a well-ventilated room without continuously operating ignition sources (e.g. open flames, an operating gas appliance, or an operating electric heater). The room size shall be as specified in the General safety precaution.



DANGER: RISK OF ELECTROCUTION

To clean the air conditioner or air filter, be sure to stop operation and turn all power supplies OFF. Otherwise, an electrical shock and injury may result.



WARNING

To prevent electrical shocks or fire:

- Do NOT rinse the unit.
- Do NOT operate the unit with wet hands.
- Do NOT place any objects containing water on the unit.



CAUTION

After a long use, check the unit stand and fitting for damage. If damaged, the unit may fall and result in injury.



CAUTION

Do NOT touch the heat exchanger fins. These fins are sharp and could result in cutting injuries.



WARNING

Be careful with ladders when working in high places.

7.2 To clean the indoor unit and wireless remote control



WARNING

Improper detergents or cleaning procedure may cause damage on plastic components or water leakage. Splashed detergent on electric components, such as motors, may cause failure, smoke or ignition.



DANGER: RISK OF ELECTROCUTION

Before cleaning, be sure to stop the operation, turn the breaker OFF or pull out the supply cord. Otherwise, an electrical shock and injury may result.




NOTICE

- Do NOT use gasoline, benzene, thinner, polishing powder or liquid insecticide. **Possible consequence:** Discoloration and deformation.
- Do NOT use water or air of 40°C or higher. **Possible consequence:** Discoloration and deformation.
- Do NOT use polishing compounds.
- Do NOT use a scrubbing brush. **Possible consequence:** The surface finishing peels off.
- As an end user, you may NEVER clean inside parts of the unit by yourself; this work must be performed by a qualified service person. Contact your dealer.

- Clean with a soft cloth. If it is difficult to remove stains, use water or a neutral detergent.


7.3 To clean the front panel




- Clean the front panel with a soft cloth. If it is difficult to remove stains, use water or a neutral detergent.

7.4 To open the front panel

- Hold the front panel on both sides and open it.



- Pull down both locks on the back of the front panel.
- Open the front panel until the support fits into the fixing tab.




- a Lock (1 on each side)
- b Backside of the front panel
- c Fixing tab
- d Support


7 Maintenance and service

7.5 To clean the air filters


- 1 Push the tab at the centre of each air filter, then pull it down.
- 2 Pull out the air filters.



- 3 Remove the titanium apatite deodorising filter and silver particle filter from the tabs.



- 4 Wash the air filters with water or clean them with a vacuum cleaner.



- 5 Soak in lukewarm water for about 10 to 15 minutes.



i INFORMATION


- If the dust does NOT come off easily, wash the air filters with a neutral detergent diluted in lukewarm water. Dry the air filters in the shade.
- Be sure to remove the titanium apatite deodorising and silver particle filters.
- It is recommended to clean the air filters every 2 weeks.

7.6 To clean the titanium apatite deodorising filter and the silver particle filter (Ag-ion filter)


i INFORMATION

Clean the filter with water every 6 months.

- 1 Remove the titanium apatite deodorising filter and the silver allergen removal air purifying filter from all 4 claws.



- 2 Remove the dust from the filter with a vacuum cleaner.



- 3 Soak the filter for 10 to 15 minutes in warm water.

Note: Do NOT remove the filter from the frame.




- 4 After washing, shake off remaining water and dry the filter in the shade. Do NOT wring out the filter when removing water.

7.7 To replace the titanium apatite deodorising filter and the silver particle filter (Ag-ion filter)

i INFORMATION

Replace the filter every 3 years.

- 1 Remove the filter from the tabs of the filter frame and replace the filter with a new one.




i INFORMATION

- Do NOT throw away the filter frame, but use it again.
- Dispose of the old filter as non-flammable waste.

To order titanium apatite deodorising filter or silver particle filters, contact your dealer.


7.8 To close the front panel

- 1 Lift the front panel slightly and remove the support from the fixing tab.



- a Backside of the front panel
- b Fixing tab
- c Support

- 2 Close the front panel.



- 3 Gently press the front panel down until it clicks.


7.9 To remove the front panel



INFORMATION


Remove the front panel only in case it **MUST** be replaced.

- 1 Open the front panel. See "7.4 To open the front panel" [p. 17].
- 2 Open the panel locks located on the back side of the panel (1 on each side).




a Panel lock

- 3 Push the right arm lightly to the right to disconnect the shaft from the shaft slot on the right side.



a Arm
b Shaft
c Shaft slot

- 4 Disconnect the front panel shaft from the shaft slot on the left side.



a Arm
b Shaft slot
c Shaft

- 5 Remove the front panel.
- 6 To re-install the front panel perform the steps in the opposite order.

7.10 To take following items into account before a long idle period

Operate the unit several hours in **fan only** mode to dry the inside of the unit.

- 1 Press **Mode** and select operation.
- 2 Press and start operation.
- 3 After operation stops, turn the breaker OFF.
- 4 Clean the air filters and replace them in their original positions.
- 5 Remove the batteries from the wireless remote control.



INFORMATION

It is recommended to have periodical maintenance performed by a specialist. For specialist maintenance, contact your dealer. Maintenance costs shall be borne by the customer.

In certain operating conditions the inside of the unit may get dirty after several seasons of use. This results in poor performance.

7.11 About the air filters

Operating the unit with dirty filters means that the filter:

- CANNOT deodorise the air,
- CANNOT clean the air,
- poor heating/cooling,
- causes odour.

List of treated articles used in Daikin products based on Regulation (EU) No 528/2012

Treated article of a biocidal product	Air resin filter
Active substance	Silver phosphate glass
Content	<0,02 %
CAS Nr.	308069-39-8
Active substance function	Antiviral and antibacterial effect
Safety Information	<p>RoHS compliant, non-toxic or corrosive.</p> <p>There are no specific PPE recommendations.</p> <p>Disposal shall comply with government and legal regulations governing the disposal of material.</p> <p>Store in the room temperature.</p> <p>Eye contact - wash with water</p> <p>Skin contact - wash with water, shouldn't affect the skin</p> <p>Inhalation - no specific hazards indicated</p>

8 Troubleshooting

If one of the following malfunctions occurs, take the measures shown below and contact your dealer.



WARNING

Stop operation and shut OFF the power if anything unusual occurs (burning smells etc.).

Leaving the unit running under such circumstances may cause breakage, electrical shock or fire. Contact your dealer.

The system **MUST** be repaired by a qualified service person.

9 Disposal

Malfunction	Measure
If a safety device such as a fuse, a breaker or an earth leakage breaker frequently actuates or the ON/OFF switch does NOT properly work.	Turn OFF the main power switch.
If water leaks from the unit.	Stop the operation.
The operation switch does NOT work well.	Turn OFF the power supply.
If the user interface display indicates the unit number, the operation lamp flashes and the malfunction code appears.	Notify your installer and report the malfunction code.

If the system does NOT operate properly except for the above mentioned cases and none of the above mentioned malfunctions is evident, investigate the system in accordance with the following procedures.



INFORMATION

Refer to the reference guide located on <https://www.daikin.eu> for more troubleshooting tips. Use the search function 🔍 to find your model.

After checking all the items above, if it is impossible to fix the problem yourself, contact your installer and state the symptoms, the complete model name of the unit (with manufacturing number if possible) and the installation date.

8.1 Troubleshooting for wireless LAN connection

The following table provides a brief description of how to deal with some problems. If none of the following solutions fix the problem, go to app.daikineurope.com for more information and FAQ.

Problem	Measure
Connection to the WLAN adapter is not possible (none of the LEDs are blinking).	<ul style="list-style-type: none"> Try operating the unit with the user interface. Check if the power is on. Turn the unit off and back on again.
The WLAN adapter is NOT visible on the unit overview screen (Home screen) after configuration of the WLAN adapter (WPS option).	<ul style="list-style-type: none"> Make sure the wireless LAN adapter is close enough to the communication device. Check if communication is OK. Make sure that the smart device is connected to the same wireless network as the WLAN adapter. Try resetting to the factory default and repeat the setting. See "To reset the connection setting to the factory default" ▶ 16].
The WLAN adapter is NOT visible in the available Wi-Fi networks list on the smart device (Access point option).	<ul style="list-style-type: none"> Try switching between access point and WPS setting to change the wireless channel. The wireless channel MUST be between 1~11. Check if communication is OK. Try resetting to the factory default and repeat the setting. See "To reset the connection setting to the factory default" ▶ 16].


Problem	Measure
Displayed indoor/outdoor temperature/humidity value in ONECTA differs from the value measured by other appliances.	<ul style="list-style-type: none"> ONECTA displays indoor/outdoor temperature/ humidity only for the indoor/outdoor unit's surrounding. Measured temperature/ humidity for other appliances may differ due to different condition around the unit (e.g. direct sunlight, frost accumulation...) Temperature/humidity displayed in ONECTA is only referential.


9 Disposal




NOTICE

Do NOT try to dismantle the system yourself: dismantling of the system, treatment of the refrigerant, oil and other parts MUST comply with applicable legislation. Units MUST be treated at a specialised treatment facility for reuse, recycling and recovery.









Copyright 2026 Daikin

DAIKIN INDUSTRIES CZECH REPUBLIC s.r.o.

U Nové Hospody 1155/1, 301 00 Plzeň Skvrňany, Czech Republic

DAIKIN EUROPE N.V.

Zandvoordestraat 300, B-8400 Oostende, Belgium

3P847164-3 2026.03